

ARTIK 56 EL Snow blower



Документы

Handle-bar and control box

Complete engine

Transmission assy

Snow thrower assy

Cylinder head

Cylinder and crankcase

Crankcase cover

Crankshaft and piston

Valves

Ignition system

Carburetor

Flywheel and coil

Starter lever

Control lever


Air filter

Muffler

Tank


Cover

Support (Box)




изображение Handle-bar and control box

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000001	Handlebar				
2	2	ZM000002	Lever				
3	2	ZM000003	Cap				
4	2	ZM000067	Lever connecting shaft				
5	1	ZM000005	Traction cable				
6	1	ZM000171	Plate				
7	1	ZM000007	Bowden cable			Rotore; Rotor	
8	1	ZM000173	Support				
9	1	ZM000174	Bush				
10	1	ZM000172	Plate				
11	1	ZM000068	Headlamp				
12	1	ZM000175	Support				
13	4	ZM000006	Bolt				




изображение Complete engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000008	Belt cover				
2	1	ZM000377	Bushing				
3	1	ZM000010	Support				
4	1	ZM000011	Bushing				
5	1	ZM000012	Spring				
6	1	ZM000013	Pulley				
7	1	ZM000014	Pulley			Dentata; Toothed	
8	1	ZM000015	Belt			AOLIDA HTD 750-5M	
9	1	ZM000016	V belt			TRUFLEX G 4LXP885	
10	1	ZM000017	Pulley				
11	1	ZM000378	Bushing				



изображение Transmission assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000018	Lever				
2	1	ZM000019	Bracket				
3	4	ZM000020	Bearing				
4	1	ZM000021	Shaft				
5	1	ZM000022	Wheel				
6	1	ZM000023	Rubber ring				
7	2	ZM000024	Flange				
8	2	ZM000025	Screw				
9	2	ZM000026	Pulley				
10	3	ZM000229	Washer				
11	1	ZM000028	Shaft				
12	1	ZM000029	Flywheel				
13	1	ZM000030	Spring				
14	1	ZM000031	Fork				
15	2	ZM000032	Sleeve				
16	1	ZM000033	Gear				
17	1	ZM000034	Complete wheel			Destra ; Right	
18	1	ZM000189	Bracket support				
19	1	ZM000193	Plate (guide)				
20	1	ZM000190	Plate				
21	1	ZM000194	Gear case assy				
22	1	ZM000101	Cover				
23	1	ZM000191	Support				
24	1	ZM000195	Support				
25	1	ZM000170	Knob				
26	1	ZM000196	Shaft				
27	1	ZM000192	Plate				
28	1	ZM000382	Complete wheel			Sinistra ; Left	




изображение Snow thrower assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000035	Pulley				
2	1	ZM000036	Bolt				
3	1	ZM000037	Spring				
4	1	ZM000038	Main board				
5	1	ZM000039	Spring				
6	1	ZM000040	Pulley				
7	1	ZM000041	Key				
8	1	ZM000042	Cover				
9	1	ZM000043	Bearing				
10	1	ZM000044	Knob				
11	1	ZM000045	Rod				
12	1	ZM000046	Main board				
13	2	ZM000047	Sliding block				
14	1	ZM000048	Plate				
15	1	ZM000049R	Fan				
16	1	ZM000050	Oil seal				
17	1	ZM000051	Bearing				
18	1	ZM000052	Bearing				
19	1	ZM000053	Shaft				
20	1	ZM000054	Bearing				
21	2	ZM000055	Bushing				
22	2	ZM000056R	Tiller dx				
23	1	ZM000057	Shaft				
24	2	ZM000058	Bushing				
25	2	ZM000059R	Tiller sx				
26	2	ZM000060	Bushing				
27	2	ZM000061	Cover				
28	3	ZM000062	Plate				
29	3	ZM000063	Plate				
30	1	ZM000064	Snow chute			Orientabile; Adjustable	
31	1	ZM000065	Spring				
32	1	ZM000066	Bracket				
33	4	ZM000166	Self-locking nut				
34	4	ZM000090	Pin				
35	1	ZM000218	Knob				
36	1	ZM000168	Shovel				
37	1	ZM000219	Cover dx				
38	1	ZM000220	Cover sx				
39	1	ZM000117R	Gear				
40	2	ZM000115	Bushing				
41	2	ZM000116	Gasket				
42	1	ZM000248	Washer				
43	2	ZM000366	Washer				
44	8	ZM000114	Guard cap				


изображение Snow thrower assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	1	ZM000221	Plate (guide)				
46	2	ZM000229	Washer				
47	1	ZM000069	Case				
48	1	ZM000169	Shovel support				
49	1	ZM000379	Bushing				
50	1	ZM000377	Bushing				
51	1	ZM000384	Battery cover				
52	1	68260001R	Battery				
53	1	ZM000388	Labels kit				




изображение Cylinder head

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150350	Plug				
2	4	L66150323	Screw				
3	1	L66150476	Gasket				
4	1	L66150477	Tube				
5	1	3055123R	Spark plug				
6	1	L66150519	Gasket				
7	1	L66150309	Gasket				
8	1	L66150603	Gasket set				
9	1	L66150602	Head comp.cylinder				




изображение Cylinder and crankcase

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150478	Seal ring				
2	1	L66150355	Bearing				
3	1	L66150302	Shaft				
4	1	L66150353	Plug				
5	1	L66150479	Governor				
6	1	L66150480	Cable				
7	2	L66150354	Washer				
8	2	L66150352	Screw				
9	1	L66150325	Washer				
10	1	L66150603	Gasket set				
11	1	L66150698	Extension hose			Corto; Short	




изображение Crankcase cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66151232	Cap				
2	1	L66150481	Seal ring				
3	1	L66150355	Bearing				
4	1	L66150274	Gasket				
5	6	L66150319	Screw				
6	1	L66150273	Crankcase cover				
7	2	L66150357	Plug				
8	1	L66150603	Gasket set				




изображение Crankshaft and piston

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150520	Piston ring set				
2	1	L66150604	Piston assy				
3	1	L66150521	Connecting rod cpl.				
4	1	L66150482	Shaft				
5	2	L66150075	Snap ring				
6	1	L66150081	Key				
7	1	L66150483	Key				
8	1	L66150077	Piston pin				




изображение Valves

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150368	Compensator				
2	1	L66150287	Plate (guide)				
3	2	L66150285	Rod				
4	2	L66150286	Slide				
5	2	L66150364	Valve				
6	2	L66150365	Ring				
7	2	L66150522	Valves spring				
8	1	L66150367	Seal				
9	1	L66150523	Valve				
10	1	L66150363	Complete shaft				
11	1	L66150602	Head comp.cylinder				




изображение Ignition system

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150485	Starter assy				
2	1	L66150330	Fixing screw				
3	1	L66150331	Clutch driver				
4	1	L66150332	Spring				
5	2	L66150263	Pawl				
6	2	L66150264	Spring				
7	1	L66150265	Pulley				
8	1	L66150336	Starter spring				
9	1	L66150486	Handle				
10	1	L66150487	Starter rope				
11	4	L66150322	Screw				
12	1	L66150488	Starter assy				
13	2	L66150339	Screw				




изображение Carburetor

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150291	Gasket				
2	1	L66150293	Insulator				
3	1	L66150290	Gasket				
4	1	L66150701	Carburetor				BT6-107-12/13
5	1	L66150292	Gasket				
6	1	L66150697	Air lever	06/13			BT6-107-12/13
7	1	L66150702	Primer pump				
8	1	L66150701	Carburetor	06/13			BT6-107-12/13




изображение Flywheel and coil

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150616	Ignition coil				
2	1	L66150491	Spark plug cap				
3	2	L66150321	Screw				
4	1	L66150526	Flywheel				
5	1	L66150288	Fan				
6	1	L66150312	Pulley				
7	1	L66150376	Nut				
8	1	L66150492	Case				
9	1	L66150493	Switch				
10	1	L66150494	Battery charger				



изображение Starter lever


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150524	Starter lever				
2	2	L66150321	Screw				
3	1	L66150615	Contact				
4	1	L66150617	Electrical box				
5	1	L66150694	Wrench				




изображение Control lever

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150495	Throttle rod				
2	1	L66150300	Spring				
3	1	L66150382	Screw				
4	1	L66150185	Nut				
5	1	L66150496	Spring				
6	1	L66150240	Screw				
7	1	L66150497	Switch (stop)				
8	1	L66150380	Spring				
9	1	L66150381	Screw				
10	1	L66150498	Complete lever				
11	1	L66150499	Rubber protection				

I° Serie / Ist Serie




II° Serie / IInd Series




изображение Air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150500	Elbow		05/13		BT6-107-12/13
2	1	L66150501	Air filter kit		05/13		BT6-107-12/13
3	1	L66150502	Starter lever		05/13		BT6-107-12/13
4	1	L66150505	Clip		05/13		BT6-107-12/13
5	1	L66150504	Knob		05/13		BT6-107-12/13
6	1	L66150705	Air filter	06/13			BT6-107-12/13




изображение Muffler

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150506	Complete muffler				
2	2	320000028R	Nut				




изображение Tank

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150507	Knob				
2	1	L66150508	Switch				
3	3	L66150185	Nut				
4	2	L66150509	Clip				
5	1	L66150510	Tube				
6	1	L66150295	Fitting				
7	4	L66150322	Screw				
8	1	L66150601	Complete tank				
9	1	L66150511	Cap				
10	1	L66150515	Tube				
11	1	L66150512	Cover				
12	1	L66150513	Complete cap				
13	1	L66150514	Filter				



изображение Cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150516	Guard				
2	1	L66150517	Guard				



изображение Support (Box)

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	3	L66150322	Screw				