

## PGE 23i S Generator



### Документы

Cylinder head

---

Air deflector

---

Crankcase

---

Crankcase cover

---

Crankshaft and piston

---

Valve train - distribution

---

Starter assy

---

Carburetor

---

Air filter

---

Generator group

---

Muffler

---

Inverter assembly

---

Tank

---

Lower frame


---

Control Panel

---


Protection cover

---



## изображение Cylinder head


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	4	L66152138	Screw				
2	1	L66152468	Breather fuel pipe				
3	1	L66152469	Cover				
4	1	L66152470	Oil filter				
5	1	L66152471	Gasket				
6	1	L66152472	Cover				
7	3	L66152473	Screw				
8	1	L66152474	Gasket				
9	4	L66152475	Screw				
10	1	L66152476	Cylinder				
29	1	L66152477	Gasket				
30	2	L66152478	Pin				
36	2	L66152479	Stud				
75	1	L66152480	Spark plug				



## изображение Air deflector

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
18	1	L66152599	Screw				
28	1	L66152481	Deflector				
57	1	L66152482	Deflector				
60	1	L66152595	Screw				
61	1	L66152484	Seal				
62	1	L66152485	Earth cable				
63	2	L66152486	Screw				
64	1	L66152487	Ignition coil				
74	1	L66152488	Fairled				



## изображение Crankcase

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
23	2	L66152107	Pin				
25	1	L66152489	Crankcase				
47	1	L66152490	Seal ring				
76	1	L66152492	Ignition module				
77	2	L66152247	Screw				





## изображение Crankcase cover


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
15	7	L66152493	Screw				
16	1	L66152598	Crankcase cover				
17	1	L66152494	Oil sensor				
18	1	L66152599	Screw				
19	2	L66152600	Screw				
20	1	L66152495	Gasket				
26	1	L66152496	Oil cap				
27	1	L66152497	Seal				
78	1	L66152498	Washer				



## изображение Crankshaft and piston


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
21	1	L66152499	Camshaft assy				
22	1	L66152500	Crankshaft				
24	1	L66152501	Bearing				
31	1	L66152502	Piston ring set				
32	2	L66152503	Ring				
33	1	L66152504	Piston				
34	1	L66152505	Complete connecting rod				
35	1	L66152506	Piston pin				



## изображение Valve train - distribution


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
65	2	L66152507	Compensator				
66	1	L66152508	Pin				
67	2	L66152509	Equalizer rod				
68	2	L66152510	Clamp				
69	2	L66152511	Slide				
70	2	L66152512	Valves spring				
71	2	L66152513	Slide				
72	1	L66152514	Seal				
73	1	L66152515	Valves kit				



## изображение Starter assy

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
55	1	L66152516	Starter assy				
56	3	L66152517	Screw				






## изображение Carburetor

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
37	1	L66152518	Gasket				
38	1	L66152519	Insulator				
39	1	L66152520	Gasket				
40	1	L66152521	Carburetor				
41	1	L66152522	Fairled				
42	1	L66152523	Tube				
44	1	L66152524	Gasket				



## изображение Air filter

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
19	2	L66152600	Screw				
45	1	L66152525	Air filter				
46	4	L66152154	Nut				



## изображение Generator group


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
43	2	L66152293	Pin				
48	1	L66152526	Stator				
49	3	L66152527	Screw				
50	1	L66152528	Nut				
51	1	L66152529	Rotor				
52	1	L66152530	Fan				
53	1	L66152531	Pulley				
54	2	L66152532	Screw				



## изображение Muffler


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
11	2	L66152533	Screw				
12	1	L66152534	Screw				
13	1	L66152535	Muffler				
14	1	L66152536	Gasket				
16	1	L66152266	Screw				
18	4	L66152562	Washer				
19	1	L66152563	Gasket				
20	1	L66152564	Panel				
21	6	L66152597	Screw				





## изображение Inverter assembly


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
21	4	L66152597	Screw				
38	1	L66152537	Panel support				
39	1	L66152538	Screw				
40	1	L66152539	Switching command				
41	1	L66152540	Switch support				
42	3	L66152595	Screw				
43	1	L66152541	Commutator				
44	1	L66152542	Choke cable				
45	3	L66152247	Screw				
46	1	L66152543	Inverter				
69	1	L66152544	Accelerator bracket				



## изображение Tank

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
28	1	L66152545	Tank cap				
29	1	L66152546	Tank cap grommet				
30	1	L66152547	Tank filter				
31	1	L66152548	Tank				
32	3	L66152549	AV-mount				
33	1	L66152550	Filter				
34	1	L66152551	Fairled				
35	1	L66152552	Tube				
37	1	L66152553	Tap				



## изображение Lower frame


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
47	1	L66152554	Lower frame				
48	1	L66152555	Support				
49	4	L66152596	Nut				
50	8	L66152556	Nut				
51	6	L66152154	Nut				
52	4	L66152557	Anti-vibration support				
53	4	L66152558	Screw				
54	4	L66152559	AV-mount				
55	4	L66152560	Bushing				
56	4	L66152090	Screw				



## изображение Control Panel

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152565	Control Panel				
2	1	L66152566	Earthing terminal				
3	4	L66152567	Screw				
4	1	L66152568	Indicators				
6	1	L66152569	Plug				
7	1	L66152570	Rubber protection				
8	1	L66152571	Switch				
9	2	L66152572	Cap				
10	1	L66152573	Socket				
11	1	L66152574	Socket				
12	1	L66152575	USB/AUX				
13	1	L66152576	Wiring				





## изображение Protection cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
22	1	L66152577	Gasket				
23	1	L66152578	Cover (Left)				
24	1	L66152579	Screw				
25	1	L66152580	Left guard				
26	1	L66152581	Deck (left)				
27	1	L66152582	Screw				
42	4	L66152595	Screw				
49	9	L66152596	Nut				
57	1	L66152583	Deck (right)				
58	4	L66152584	Screw				
59	2	L66152585	AV-mount				
60	1	L66152586	Right guard				
61	1	L66152587	Cover				
62	1	L66152588	Cover (right)				
63	1	L66152589	Cap				
64	1	L66152590	Cap				
65	1	L66152591	Cap				
66	1	L66152592	Cap				
67	4	L66152593	Screw				
68	1	L66152594	Oil window				