

## PGE 25 DCS Generator



### Документы

Cylinder head

---

Crankcase

---

Crankcase cover

---

Crankshaft and piston

---

Starter assy

---

Valve train - distribution

---

Conveyor group

---

Carburetor

---

Ignition group

---

Control levers

---

Air filter

---

Muffler

---

Tank

---

Control Panel


---

Frame

---

Generator group


---



## изображение Cylinder head


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152081	Cylinder				
2	2	L66152082	Stud				
3	2	L66152083	Pin				
4	1	L66152084	Gasket				
5	2	L66152085	Stud				
6	1	L66152086	Spark plug				
7	4	L66152087	Screw				
8	1	L66152088	Gasket				
9	1	L66152089	Cover				
10	4	L66152090	Screw				
11	1	L66152091	Breather fuel pipe				




## изображение Crankcase

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152092	Crankcase				
2	1	L66152093	Seal ring				
3	2	L66152094	Washer				
4	2	L66152095	Screw				
5	1	L66152096	Guard				
6	1	L66152097	Screw				
7	1	L66152098	Oil sensor				
8	2	L66152090	Screw				
9	1	L66152099	Governor				
10	1	L66152100	Bearing				
11	1	L66152101	Washer				
12	1	L66152102	Clip				
13	1	L66152103	Regulating lever				



## изображение Crankcase cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	6	L66152104	Screw				
2	1	L66152105	Crankcase cover				
3	1	L66152106	Oil cap				
4	1	L66152093	Seal ring				
5	1	L66152100	Bearing				
6	2	L66152107	Pin				
7	1	L66152108	Gasket				






## изображение Crankshaft and piston

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152109	Piston ring set				
2	2	L66152110	Ring				
3	1	L66152111	Piston				
4	1	L66152112	Piston pin				
5	2	L66152113	Bolt				
6	1	L66152114	Complete connecting rod				
7	1	L66152115	Key				
8	1	L66152116	Crankshaft				



## изображение Starter assy



---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152118	Starter assy				
2	3	L66152119	Screw				
3	1	L66152120	Starter case				
4	4	L66152097	Screw				



## изображение Valve train - distribution


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152125	Plate				
2	2	L66152126	Equalizer rod				
3	2	L66152127	Slide				
4	2	L66152128	Valve cap				
5	2	L66152129	Spring holder				
6	2	L66152130	Valves spring				
7	1	L66152131	Seal				
8	1	L66152132	Valves kit				
9	1	L66152133	Camshaft assy				
10	2	L66152134	Compensator				



## изображение Conveyor group

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66152135	Screw				
2	1	L66152136	Deflector				
3	1	L66152137	Side conveyor				
4	1	L66152138	Screw				
5	1	L66152139	Clamp				






## изображение Carburetor

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152140	Carburetor				
2	1	L66152141	Gasket				
3	1	L66152142	Gasket				
4	1	L66152143	Insulator				
5	1	L66152144	Gasket				



## изображение Ignition group

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152145	Flywheel				
2	1	L66152146	Ignition coil				
3	2	L66152147	Screw				
4	1	L66152148	Fan				
5	1	L66152149	Pulley				
6	1	L66152150	Nut				



## изображение Control levers

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66152097	Screw				
2	1	L66152151	Spring				
3	1	L66152152	Screw				
4	1	L66152153	Regulator rod				
5	1	L66152154	Nut				
6	1	L66152155	Spring				
7	1	L66152156	Throttle rod				
8	1	L66152157	Accelerator group				
9	1	L66152158	Spring				
10	1	L66152159	Screw				



## изображение Air filter

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152160	Filter cover				
2	1	L66152163	Air filter				
3	1	L66152164	Filter support				
4	1	L66152165	Seal ring				
5	1	L66152166	Filter support				
6	1	L66152141	Gasket				






## изображение Muffler

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152168	Gasket				
2	2	L66152169	Nut				
3	1	L66152170	Muffler				
4	2	L66152171	Screw				
5	1	L66152172	Muffler support				
6	5	L66152173	Screw				



## изображение Tank


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152174	Tank cap				
2	1	L66152175	Filter				
3	1	L66152176	Clip				
4	2	L66152177	Screw				
5	1	L66152178	Oil level				
6	4	L66152182	AV-mount				
7	1	L66152183	Tank				
8	1	L66152184	Tap				




## изображение Control Panel

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152189	OM control panel				
2	4	L66152090	Screw				
3	1	L66152190	Negative terminal				
4	1	L66152191	Positive terminal				
5	1	L66152192	Starting switch				
6	1	L66152193	Timer				
7	2	L66152194	Plug				
8	1	L66152195	Electrical protection				
9	1	L66152196	Rectifier				
10	1	L66152197	Electrical protection				
11	6	L66152199	Nut				



## изображение Frame

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152201	Frame				
2	8	L66152202	Nut				
3	1	L66152203	AV-mount				
4	1	L66152154	Nut				
5	4	L66152204	AV-mount				
6	3	L66152090	Screw				
7	1	L66152101	Washer				
8	1	L66152206	Earth cable				
9	1	L66152147	Screw				
10	1	L66152208	Bracket				
11	1	L66152209	Guard				
12	3	L66152210	Screw				
13	3	L66152211	Nut				





## изображение Generator group

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152212	Electric motor				
2	1	L66152213	Brush				
3	1	L66152214	Limiter switch				
4	1	L66152215	Engine support				
5	4	L66152217	Screw				
6	1	L66152219	Governor				
7	1	L66152220	Motor protection				
8	7	L66152221	Screw				
9	1	L66152222	Bracket				