

## PGE 65E DCS Generator



### Документы

Engine

---

Cylinder head

---

Crankcase

---

Crankcase cover

---

Crankshaft and piston

---

Valve train - distribution

---

Starter assy

---

Electric starter assembly

---

Carburetor

---

Ignition group (1/2)

---

Ignition group (2/2)

---

Air filter

---

Control levers

---

Muffler

---

Tank

---

Generator group

---

Frame

---

Control Panel


---

Battery

---

Transport wheels


---



## изображение Engine


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152266	Screw				
2	1	L66152267	Cover				
3	1	L66152247	Screw				
4	1	L66152268	Bracket				
5	1	L66152269	Cover				




## изображение Cylinder head

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152418	Cylinder				
2	1	L66152272	Screw				
3	1	L66152273	Cover				
4	2	L66152274	Stud				
5	2	L66152085	Stud				
6	1	L66152086	Spark plug				
7	1	L66152275	Seal ring				
8	1	L66152419	Gasket				
9	4	L66152277	Screw				
10	1	L66152278	Breather fuel pipe				
11	2	L66152279	Pin				
12	1	L66152247	Screw				
13	1	L66152280	Deflector				



## изображение Crankcase


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66152090	Screw				
2	1	L66152281	Oil sensor				
3	1	L66152282	Bearing				
4	1	L66152283	Washer				
5	1	L66152102	Clip				
6	1	L66152284	Regulating lever				
7	1	L66152285	Seal ring				
8	2	L66152286	Screw				
9	2	L66152287	Washer				
10	1	L66152459	Crankcase				
11	1	L66152247	Screw				
12	2	L66152289	Fairled				
13	1	L66152096	Guard				
14	1	L66152295	Seal ring				
15	1	L66152270	Stud				





## изображение Crankcase cover


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152290	Oil cap				
2	1	L66152291	Governor				
3	1	L66152282	Bearing				
4	1	L66152292	Bearing				
5	2	L66152293	Pin				
6	1	L66152294	Gasket				
7	1	L66152295	Seal ring				
8	1	L66152296	Crankcase cover				
9	7	L66152297	Screw				



## изображение Crankshaft and piston


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152421	Piston ring set				
2	2	L66152299	Ring				
3	1	L66152422	Piston				
4	1	L66152301	Piston pin				
5	1	L66152423	Complete connecting rod				
6	2	L66152303	Bolt				
7	1	L66152424	Crankshaft				
8	1	L66152115	Key				
9	1	L66152425	Shaft				



## изображение Valve train - distribution


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66152306	Compensator				
2	2	L66152307	Seal				
3	4	L66152308	Clamp				
4	2	L66152309	Spring holder				
5	2	L66152310	Valves spring				
6	1	L66152311	Slide				
7	1	L66152312	Seal				
8	1	L66152426	Valves kit				
9	1	L66152314	Balance plate				
10	2	L66152315	Equalizer rod				
11	2	L66152316	Slide				
12	1	L66152427	Camshaft assy				



## изображение Starter assy

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152429	Starter assy				
2	3	L66152119	Screw				
3	1	L66152430	Starter case				
4	5	L66152247	Screw				
5	1	L66152454	Fairled				






## изображение Electric starter assembly

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152397	Start motor assy				
2	2	L66152398	Screw				
3	1	L66152399	Relay				
4	2	L66152373	Screw				



## изображение Carburetor

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152431	Carburetor				
2	1	L66152460	Lever				
3	1	L66152325	Gasket				
4	1	L66152326	Insulator				
5	1	L66152327	Gasket				
6	1	L66152328	Gasket				



## изображение Ignition group (1/2)

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152331	Flywheel				
2	1	L66152332	Fan				
3	1	L66152333	Pulley				
4	1	L66152334	Nut				



## изображение Ignition group (2/2)

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152335	Ignition coil				
2	2	L66152147	Screw				
3	1	L66152454	Fairled				
4	1	L66152340	Fairled				
5	1	L66152337	Charging plates				
6	2	L66152338	Screw				
7	1	L66152339	Plate				
8	1	L66152247	Screw				





## изображение Air filter


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66152341	Clip				
2	1	L66152342	Filter cover				
3	1	L66152345	Air filter				
4	6	L66152461	Nut				
5	1	L66152346	Filter support				
6	1	L66152347	Seal ring				
7	1	L66152348	Filter support				
8	1	L66152328	Gasket				
9	2	L66152154	Nut				



## изображение Control levers


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152350	Accelerator group				
2	2	L66152247	Screw				
3	1	L66152434	Spring				
4	1	L66152352	Spring				
5	1	L66152353	Throttle rod				
6	1	L66152254	Nut				
7	1	L66152152	Screw				
8	1	L66152354	Rod support				




## изображение Muffler

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152355	Gasket				
2	2	L66152169	Nut				
3	2	L66152356	Screw				
4	1	L66152435	Exhaust pipe				
5	1	L66152358	Gasket				
6	2	L66152436	Muffler				
7	1	L66152359	Screw				



## изображение Tank


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152174	Tank cap				
2	1	L66152175	Filter				
3	1	L66152176	Clip				
4	2	L66152177	Screw				
5	1	L66152178	Oil level				
6	4	L66152182	AV-mount				
7	1	L66152437	Tank				
8	1	L66152184	Tap				
9	1	L66152329	Tube				
10	1	L66152330	Sleeve				
11	1	L66152362	AV-mount				






## изображение Generator group

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152438	Electric motor				
2	1	L66152364	Terminal plate				
3	1	L66152365	Brush				
4	1	L66152366	Engine support				
5	1	L66152287	Washer				
6	4	L66152439	Screw				
7	2	L66152440	Screw				
8	1	L66152441	Screw				
9	1	L66152442	Governor				
10	1	L66152372	Cover				
11	3	L66152373	Screw				
12	6	L66152221	Screw				
13	1	L66152374	Limiter switch				
14	1	L66152443	Bracket				
15	1	L66152375	Cover				





## изображение Frame

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152444	Frame				
2	4	L66152379	Nut				
3	1	L66152380	AV-mount				
4	4	L66152202	Nut				
5	1	L66152154	Nut				
6	1	L66152101	Washer				
7	1	L66152382	Earth cable				
8	1	L66152147	Screw				
9	1	L66152445	Guard				
10	3	L66152384	Screw				
11	3	L66152446	Nut				



## изображение Control Panel


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152463	OM control panel				
2	4	L66152090	Screw				
3	1	L66152190	Negative terminal				
4	1	L66152191	Positive terminal				
5	1	L66152387	Starting switch				
6	1	L66152193	Timer				
7	2	L66152194	Plug				
8	1	L66152389	Plug				
9	1	L66152195	Electrical protection				
10	1	L66152449	Electrical protection				
11	1	L66152450	Cover				
12	1	L66152196	Rectifier				
13	2	L66152451	Electrical protection				



## изображение Battery

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152464	Wire				
2	1	L66152466	Bracket				





## изображение Transport wheels

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66152452	Lever				
2	1	L66152453	Rubber handle				
3	2	L66152402	Lever				
4	1	L66152415	Cap				
5	1	L66152455	Lever support				
6	3	L66152406	Nut				
7	1	L66152407	Screw				
8	4	L66152405	Screw				
9	4	L66152359	Screw				
10	2	L66152408	Anti-vibration support				
11	4	L66152202	Nut				
12	2	L66152409	AV-mount				
13	2	L66152101	Washer				
14	2	L66152410	Screw				
15	2	L66152154	Nut				
16	2	L66152413	Washer				
17	2	L66152414	Clip				
18	2	L66152412	Wheel				
19	2	L66152411	Pin				