

## MH 175 RKS (K800 HT - EURO5) Rotary tiller



### Документы

Gears

---

Frame

---

Unit (Bonnet)

---

Tiller

---

Handlebar

---

Top cover

---

Crankcase

---

Crankcase cover

---

Shaft + piston

---

Valve

---

Ignition system

---

Carburetor

---

Flywheel and coil

---

Control lever

---

Air filter


---

Muffler

---


Tank

---




## изображение Gears

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151105	Case				
2	2	L66151106	Oil seal				
3	2	L66151107	Bearing				
4	1	L66151108	Shaft				
5	1	L66151109	Chain				
6	1	L66151110	Case				
7	2	L66151111	Bearing				
8	1	L66151112	Gear				
9	14	L66150885	Nut				
10	10	L66150393	Screw				
11	4	L66150884	Nut				
12	4	L66150924	Bolt				
13	1	L66151113	Cap				
14	4	L66150456	Screw				
15	2	L66151114	Bracket				




## изображение Frame

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
2	14	L66150894	Washer				
3	14	L66150884	Nut				
4	4	L66150901	Bolt				
5	1	L66151115	Front wheel				
6	1	L66151116	Nut				
7	1	L66151117	Pin				
8	1	L66151118	Fork				
9	2	L66150902	Pin				
10	1	L66151119	Pin				
11	1	L66151120	Bolt				
12	1	L66150922	Washer				
13	1	L66150885	Nut				
14	1	L66151121	Bracket				
15	2	L66151648	Fender				
16	6	L66150317	Screw				
17	1	L66151649	Arm				
18	4	L66150047	Screw				
19	4	L66151124	Fixing plate				
20	1	L66151119	Pin				
21	2	L66150883	Clip				
22	1	L66151125	Wrench				



## изображение Unit (Bonnets)


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	4	L66150317	Screw				
2	2	L66150393	Screw				
3	1	L66151126	Sleeve				
4	4	L66150884	Nut				
5	1	L66151127	Plate				
6	2	L66151128	Bushing				
7	2	L66150894	Washer				
8	1	L66150922	Washer				
9	2	L66150885	Nut				
10	1	L66151129	Spring				
11	2	L66151130	Bushing				
12	2	L66151131	Washer				
13	1	L66151132	Strap				
14	1	L66151133	Strap				
15	2	L66151134	Bolt				
16	1	L66151135	Belt			Lung./Length = 10 x 955 Li	
17	1	L66151136	Pulley				
18	2	L66150893	Bearing				
19	1	L66150899	Bolt				
20	1	L66151137	Bolt				
21	1	L66151138	Guide pulley				
22	1	L66151139	Guide pulley				
23	1	L66151140	Bolt				
24	1	L66151141	Belt			Lung./Length = 13 x 1065	
25	3	L66150393	Screw				
26	1	L66151657	Cover				
27	1	L66151142	Spring				
28	1	L66150921	Plate				
29	1	L66151909	Label				





## изображение Tiller

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	24	L66150973	Bolt				
2	12	L66150974	Knife				
3	12	L66150975	Knife				
4	24	L66150976	Washer				
5	24	L66150977	Nut				
6	2	L66151144	Support				
7	2	L66150979	Support				
8	2	L66150980	Disk				
9	4	L66150883	Clip				
10	1	L66151146	Cutters kit				
11	1	L66151147	Cutters kit				




## изображение Handlebar

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151162	Guard				
2	1	L66151149	Lever				
3	1	L66151165	Washer				
4	1	L66151651	Gear				
5	1	L66151152	Nut				
6	1	L66151652	Handlebar				
7	1	L66151653A	Throttle cable				
8	1	L66151155	Transmission				
9	1	L66151654	Transmission				
10	2	L66151143	Knob				
11	1	L66151655	Lever				


8\*

9●



## изображение Top cover


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	4	L66150322	Screw				
2	1	L66150707	Cover				
3	1	L66150476	Gasket				
4	1	3055123R	Spark plug				
5	4	L66150323	Screw				
6	2	L66150324	Stud				
7	1	L66150309	Gasket				
8	1	L66151888	Gasket set				
9	1	L66151626	Head comp.cylinder				
10	2	L66150350	Plug				
11	2	L66150241	Stud				



2\*

## изображение Crankcase


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151174	Crankcase				
2	1	L66151888	Gasket set				
4	1	L66150462	Oil seal				
5	1	L66150304	Governor				
6	1	L66150355	Bearing				
7	2	L66150352	Screw				
8	2	L66150354	Washer				
11	1	L66150302	Shaft				
12	1	L66150353	Plug				
13	1	L66150325	Washer				
14	1	L66150480	Cable				





## изображение Crankcase cover


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66151232	Cap				
2	6	L66150319	Screw				
3	1	L66151176	Crankcase cover				
4	1	L66150462	Oil seal				
5	1	L66150355	Bearing				
6	2	L66150357	Plug				
7	1	L66151175	Gasket				
8		L66151888	Gasket set				



## изображение Shaft + piston



---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151620	Piston ring set				
2	2	L66150372	Retainer washer				
3	1	L66151627	Piston assy				
4	1	L66150342	Piston pin				
5	1	L66150373	Complete shaft				
6	1	L66150081	Key				
7	1	L66150281	Connecting rod cpl.				



## изображение Valve


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150368	Compensator				
2	1	L66151626	Head comp.cylinder				
5	1	L66150287	Plate (guide)				
6	2	L66150285	Rod				
7	2	L66150286	Slide				
8	2	L66150364	Valve				
9	2	L66150365	Ring				
10	2	L66150522	Valves spring				
11	1	L66150367	Seal				
12	1	L66150523	Valve				
13	1	L66151628	Camshaft assy				
15	1	L66151125	Wrench				
16	1	L66151178	Oil seal				



## изображение Ignition system

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150374	Starter assy				
2	1	L66150329	Starter assy				
3	4	L66151621	Hex nut				
4	1	L66150391	Fan cover				
5	1	L66150725	Deflector				
6	2	L66150339	Screw				






## изображение Carburetor

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151956	Carburetor				
2	1	L66151888	Gasket set				
4	1	L66150842	Insulator				



## изображение Flywheel and coil

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150440	Clip				
2	1	L66150313	Flywheel				
3	1	L66150288	Fan				
4	1	L66150312	Pulley				
5	1	L66150376	Nut				
6	1	L66151623	Ignition coil				
7	2	L66150321	Screw				



## изображение Control lever


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151252	Throttle lever				
2	2	L66151169	Screw				
3	1	L66151253	Spring				
4	1	L66150298	Throttle rod				
5	1	L66150300	Spring				
6	1	L66150382	Screw				
7	1	004400959R	Nut				
8	1	L66150843	Arm				



## изображение Air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150307	Air filter kit				
2	1	L66150384	Nut				
3	1	L66150385	Cover				
4	1	L66150387	Filter				
5	1	L66151177	Grid				
6	1	L66150389	Filter support				
7	1	L66150473	Tube				
8	1	L66150390	Fitting				
9	2	L66150185	Nut				






## изображение Muffler

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151170	Muffler				
2	2	320000028R	Nut				
3	1	L66150317	Screw				
4	1	L66150310	Guard				



## изображение Tank

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151624	Tank cap				
2	1	L66150296	Fuel filter				
3	4	L66150316	Screw				
4	1	L66151235	Complete tank				
5	1	L66150305	Support				
6	1	L66150306	Support				
7	4	L66150321	Screw				
8	1	L66150295	Fitting				
9	2	L66150328	Band				
10	1	L66151625	Oil line				