

C 19/20 Spraying pump




Документы

Starter assy and engine (From 07/03/08)

Starter assy and engine (Until 06/03/08)

Spraying pump

Carburetor SHA14-12L




изображение Starter assy and engine (From 07/03/08)

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	094600097AR	Spark plug cap				
2	1	301000379R	Ignition coil				
3	2	094000097	Screw				
4	2	3819005R	Washer				
5	2	3916004R	Washer				
6	1	301000342AR	Support				
7	1	3818011AR	Washer				
8	1	3819013R	Grower				
9	1	320000028R	Nut				
10	2	004000436R	Pin				
11	2	300000038R	Pawl				
12	2	300000040R	Spring				
13	1	301000384R	Flywheel				
14	1	301000003R	Support				
15	4	3801009R	Screw				
16	1	300000025	Gasket				
17	1	300000022R	Tank cap				
18	1	301000348AR	Starter assy				
19	1	301000049	Felt				
20	1	3055098R	Ring				
21	1	3049006R	O-ring				
22	1	3055049R	Tap				
23	1	300000026AR	Tube				
24	1	301000346R	Fuel tank				
25	2	3960073R	Screw				
26	1	2317013R	Guard				
27	1	093500397R	Starter handle				
28	1	4098073R	Starter rope				
29	1	094600041AR	Screw				
30	2	3960081AR	Screw				
31	1	094600169AR	Spring				
32	1	2317021R	Switch				
33	1	004000132R	Spring				
34	1	300000016R	Pulley				
35	1	3918006R	Washer				
36	1	3801008R	Screw				
37	1	302000007DR	Carburetor H190-1				
38	1	301000025BR	Manifold				
39	1	301000026	Gasket				
40	1	3055101R	Spark plug				
41	4	3801013R	Screw				
42	1	301000365B	Complete cylinder Ø40				
43	1	375200078R	Gasket				
44	2	004900061R	Ring				

изображение Starter assy and engine (From 07/03/08)

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	1	301000035R	Piston pin				
46	2	074000405R	Piston ring				
47	1	301000375B	Piston assy Ø40				
48	2	3050015AR	Seal ring				
49	2	3034012R	Bearing				
50	1	301000395AR	Crankshaft				BT6-070-03/08
51	1	3037005R	Bearing				
52	1	301000047R	Key				
53	1	300000035R	Gasket				
54	1	301000357AR	Muffler				
55	2	005400303R	Screw				
56	2	3819006R	Washer				
57	1	375200071AR	Muffler cover				
58	1	301000408	Crankcase assy				BT6-070-03/08
59	4	3801066	Screw				
61	1	301000113A	Gasket set				
62	1	301000349	Cable				
67	2	3960092AR	Screw				
68	1	354000115	Engine support				





изображение Starter assy and engine (Until 06/03/08)

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	094600097AR	Spark plug cap				BT6-063-05/07
2	1	301000419	Flywheel and coil kit				BT6-063-05/07
3	2	094000097	Screw				
4	2	3819005R	Washer				
5	2	3916004R	Washer				
6	1	301000342AR	Support				
7	1	3818011AR	Washer				
8	1	3819013R	Grower				
9	1	320000028R	Nut				
10	2	004000436R	Pin				BT6-063-05/07
11	2	300000038R	Pawl				BT6-063-05/07
12	2	300000040R	Spring				BT6-063-05/07
13	1	301000419	Flywheel and coil kit				BT6-063-05/07
14	1	301000003R	Support				
15	4	3801009R	Screw				
16	1	300000025	Gasket				
17	1	300000022R	Tank cap				
18	1	301000348AR	Starter assy				
19	1	301000049	Felt				
20	1	3055098R	Ring				
21	1	3049006R	O-ring				
22	1	3055049R	Tap				
23	1	300000026AR	Tube				
24	1	301000346R	Fuel tank				
25	2	3960073R	Screw				
26	1	2317013R	Guard				
27	1	093500397R	Starter handle				
28	1	4098073R	Starter rope				
29	1	094600041AR	Screw				
30	2	3960081AR	Screw				
31	1	094600169AR	Spring				BT6-063-05/07
32	1	2317021R	Switch				
33	1	004000132R	Spring				
34	1	300000016R	Pulley				
35	1	3918006R	Washer				
36	1	3801008R	Screw				
37	1	302000007DR	Carburetor H190-1				
38	1	301000025BR	Manifold				
39	1	301000026	Gasket				
40	1	005000019R	Spark plug				
41	4	3801013R	Screw				
42	1	301000365B	Complete cylinder Ø40				
43	1	375200078R	Gasket				
44	2	004900061R	Ring				

изображение Starter assy and engine (Until 06/03/08)

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	1	301000035R	Piston pin				
46	2	074000405R	Piston ring				
47	1	301000375B	Piston assy Ø40				
48	2	3050015AR	Seal ring				
49	2	3034012R	Bearing				
50	1	301000054A	Crankshaft				
51	1	3037005R	Bearing				
52	1	301000047R	Key				
53	1	300000035R	Gasket				
54	1	301000357AR	Muffler				
55	2	005400303R	Screw				
56	2	3819006R	Washer				
57	1	375200071AR	Muffler cover				
58	1	301000408	Crankcase assy				BT6-063-05/07
59	4	3801066	Screw				
61	1	301000113A	Gasket set				
62	1	301000349	Cable				
63	1	301000095	Starter assy				
64	1	301000010	Spring				
65	1	301000011	Button				
66	1	005000122R	Starter handle				
67	2	3960092AR	Screw				
69	1	3026003R	Ring				
70	1	301000042R	Screw				
71	1	301000081	Piston assy Ø40				
72	1	301000024R	Ignition coil				
73	1	341000009	Guard				
74	1	006000829R	Washer				
75	1	301000379R	Ignition coil				BT6-063-05/07
76	1	301000384R	Flywheel				BT6-063-05/07
77	1	354000115	Engine support				



изображение Spraying pump


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	354000035	Fitting				
2	1	354000034	Spring				
3	1	354000084	Lever				
4	1	354000036	Rod				
5	1	354000037	Plug				
6	1	354000038	Gasket				
7	1	CH32180015	Top cover				
8	1	354000032	Screw				
9	2	354000031	Disk				
10	2	354000030	Diaphragm				
11	2	354000029	Cylinder				
12	1	354000060	Ring				
13	1	354000058	Piston				
14	1	354000061	Connecting rod				
15	1	354000059	Plug				
16	1	354000009	Diaphragm				
17	1	354000008	Diaphragm				
18	12	320000028R	Nut				
19	1	375200004	Screw				
20	1	354000007	Accumulator				
21	1	354000039	Valve				
22	2	354000057	Gasket				
23	1	354000010	Handle				
24	2	354000042	Seal ring				
25	1	354000043	Washer				
26	1	354000044	Shaft				
27	1	354000046	Gears				
28	1	354000045	O-ring				
29	1	3035015R	Bearing				
30	1	354000002	Support				
31	4	3914003R	Nut				
32	4	354000048	Screw				
33	1	354000047A	U-bolt				
34	1	354000069	Valve				
35	1	3049011	O-ring				
36	1	354000070	Valve				
37	1	3049018R	O-ring				
38	1	354000054	Screw				
39	1	354000012	Top cover				
40	1	CH28030516	Fittings				
41	1	3914002	Nut				
42	1	354000041	Spacer				
43	4	380000025	Bushing				
44	4	034000013R	Nut				

изображение Spraying pump

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	1	3916005R	Washer				
46	1	354000013	Fitting				
47	1	354000014	Fitting				
48	1	354000056	O-ring				
49	2	CH12000065	Fitting				
50	1	354000017	Cap				
51	1	3918006R	Washer				
52	1	354000022	Screw				
53	1	354000021	Gasket				
54	1	354000108	Complete valve				
55	1	354000018	Hub				
56	1	354000018	Hub				
57	1	354000026	O-ring				
58	1	354000024	Fittings				
59	1	354000025	Fitting				
62	1	3050015AR	Seal ring				
63	1	351000067	Fitting				
64	1	UU16030096R	Lance				
65	1	351000063	Filter				
66	1	CH32020254	Cap				
67	1	354000082	Ring nut				
68	1	354000083	Gasket				
69	1	354000084	Lever				
70	1	354000034	Spring				
71	1	354000086	Guide				
72	1	354000087	O-ring				
73	1	CH12100461	O-ring				
74	1	354000089A	Valve body				
75	1	354000090	O-ring				
76	1	CH36000058	Valve				
77	1	354000092	Seat				
78	1	354000093	O-ring				
79	1	354000094	Body				
80	1	354000095	Cap				
81	1	354000096	Nipple				
82	1	354000097	Gasket				
83	1	354000098	Fitting				
84	1	354000025	Fitting				
85	1	CH12100780	O-ring				
86	1	354000101	Ring nut				
87	1	354000102	Fitting				
88	1	354000103	O-ring				
89	1	354000037	Plug				
90	1	354000105	Hook				

изображение Spraying pump

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
91	1	354000106	Screw				
92	1	354000107	Washer				
93	1	354000108	Complete valve				
94	1	CH18160115	Pressure gauge				
95	1	354000001	Pump body				



изображение Carburetor SHA14-12L

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	300000074	Lever group				
2	1	302000157	Valve				
3	1	300000267	Gasket				
4	1	300000266	Bushing				
5	1	3801026R	Screw				
6	1	300000217	Fuel filter				
7	1	300000216R	Fittings				
8	1	300000215	Screw				
9	1	300000222R	Needle				
10	1	300000225	Pin				
11	1	302000156	Jet 58				
12	1	300000198	Float				
13	1	300000073	Gasket set				
14	1	300000079	Tank				
15	1	365200077	Air filter kit				
16	2	006000315R	Washer				
17	1	034000013R	Nut				
18	1	300000221	Screw				
19	1	300000220	Spring				
20	1	300000195	Valve				
21	1	300000226	Clamp				
22	1	300000227	Spring				
23	1	300000228	Pin				
24	2	3908005	Screw				
25	2	365200072R	Filter				
26	1	365200074R	Spring				
27	1	302000007DR	Carburetor H190-1				