

ARTIK 52 Snow blower



Документы

Handle-bar and control box

Complete engine

Transmission assy

Snow thrower assy

Cylinder head

Cylinder and crankcase

Crankcase cover

Crankshaft and piston

Valves

Ignition system

Carburetor


Flywheel and coil

Control lever

Air filter


Muffler

Tank




изображение Handle-bar and control box

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000259	Lower handle				
2	2	ZM000260	Knob				
3	1	ZM000174	Bush				
4	1	ZM000264	Support				
5	1	ZM000261	Handle			Comando frizione ; Clutch control	
6	1	ZM000262	Upper handle				
7	1	ZM000263	Clamp				
8	1	ZM000265	Adjust. pin				
9	1	ZM000246	Adjuster nut				
10	1	ZM000266	Clutch cable				




изображение Complete engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000239	Exhaust guard				
2	1	ZM000240	Pulley				
3	1	ZM000241	Support				
4	1	ZM000243	Shaft				
5	1	ZM000244	Key				
6	1	ZM000245	Bearing				
7	1	ZM000289	Flange				
8	1	ZM000247	Pulley				
9	1	ZM000248	Washer				
10	1	ZM000242	Countershaft support				



изображение Transmission assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000251	Plate				
2	2	ZM000252	Bearing				
3	1	ZM000253	Bushing				
4	1	ZM000254	Spring				
5	1	ZM000258	Pin				
6	1	ZM000255	Support				
7	2	ZM000256	Bushing				
8	1	ZM000257	Pulley				




изображение Snow thrower assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	ZM000267	Knob				
2	1	ZM000268	Deflector				
3	1	ZM000269	Snow chute				
4	1	ZM000270	Bracket				
5	1	ZM000065	Spring				
6	1	ZM000276	Knob				
7	1	ZM000275	Rod				
8	1	ZM000274	Tube				
9	1	ZM000213	Bush				
10	1	ZM000273	Support				
11	3	ZM000271	Plate				
12	1	ZM000277	Cover				
13	1	ZM000278	Tube support				
14	2	ZM000027	Bearing				
15	1	ZM000279	Shaft				
16	2	ZM000272	Tiller				
17	1	ZM000285	Cover				
18	1	ZM000287	Belt				
19	1	ZM000288	Pulley				
20	1	ZM000286	Key				
21	1	ZM000283	Fixing plate				
22	1	ZM000282	Sliding block				
23	2	ZM000280	Cover				
24	1	ZM000281	Hood				
25	2	ZM000284	Wheel				
26	1	ZM000386	Labels kit				

9●


8*



изображение Cylinder head


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150350	Plug				
2	1	L66150619	Gasket				
3	2	L66150324	Stud				
4	1	3055123R	Spark plug				
5	4	L66150323	Screw				
6	1	L66150476	Gasket				
7	4	L66150322	Screw				
8	1	L66150620	Gasket set				
9	1	L66150621	Head comp.cylinder				

12*




изображение Cylinder and crankcase

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150478	Seal ring				
2	2	L66150354	Washer				
3	2	L66150352	Screw				
4	1	L66151959	Governor				
5	1	L66150623	Oil level plug				
6	2	L66150322	Screw				
7	1	L66150304	Governor				
8	1	L66150355	Bearing				
9	1	L66150325	Washer				
10	1	L66150353	Plug				
11	1	L66150302	Shaft				
12	1	L66150620	Gasket set				




изображение Crankcase cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66151232	Cap				
2	6	L66150319	Screw				
3	1	L66150625	Crankcase cover				
4	1	L66150481	Seal ring				
5	1	L66150355	Bearing				
6	2	L66150357	Plug				
7	1	L66150626	Gasket				
8	1	L66150620	Gasket set				




изображение Crankshaft and piston

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150628	Piston ring set				
2	2	L66150075	Snap ring				
3	1	L66150077	Piston pin				
4	2	L66150078	Connecting rod bolt				
5	1	L66150629	Connecting rod cpl.				
6	1	L66150081	Key				
7	1	L66150630	Shaft				
8	1	L66150631	Key				
9	1	L66150505	Clip				
10	1	L66150632	Piston assy				




изображение Valves

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150287	Plate (guide)				
2	2	L66150285	Rod				
3	2	L66150403	Slide				
4	2	L66150364	Valve				
5	2	L66150365	Ring				
6	2	L66150366	Valves spring				
7	1	L66150484	Slide				
8	1	L66151233	Reed valve kit				
9	1	L66150633	Complete shaft				
10	1	L66150368	Compensator				
11	1	L66150621	Head comp.cylinder				




изображение Ignition system

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150635	Starter assy				
2	1	L66150636	Starter assy				
3	5	L66150339	Screw				
4	1	L66150637	Switch				
5	1	L66150638	Clip				




изображение Carburetor

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150639	Carburetor				
2	1	L66150291	Gasket				
3	1	L66150293	Insulator				
4	1	L66150290	Gasket				
5	1	L66150292	Gasket				




изображение Flywheel and coil

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150640	Flywheel				
2	1	L66150314	Ignition coil				
3	2	L66150321	Screw				
4	1	L66150641	Fan				
5	1	L66150147	Pulley				
6	1	L66150376	Nut				
7	1	L66150371	Spark plug cap				




изображение Control lever

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150642	Complete lever				
2	1	L66150380	Spring				
3	1	L66150381	Screw				
4	1	L66150643	Spring				
5	1	L66150300	Spring				
6	1	L66150495	Throttle rod				
7	1	L66150382	Screw				
8	1	L66150185	Nut				
9	1	L66150301	Arm				




изображение Air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150644	Air filter				
2	2	L66150384	Nut				
3	1	L66150645	Air filter cover				
4	2	L66150386	Screw				
5	1	L66150646	Air filter				
6	1	L66150648	Oil seal				
7	2	L66150185	Nut				



изображение Muffler

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151484	Complete muffler				
2	2	320000028R	Nut				
3	1	L66150651	Gasket				
4	1	L66150652	Cover				



изображение Tank

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150297	Cap				
2	1	L66150634	Filter				
3	2	L66150185	Nut				
4	1	L66150295	Fitting				
5	1	L66150328	Band				
6	1	L66150327	Fuel line				
7	1	L66150321	Screw				
8	1	L66150624	Washer				
9	1	L66150627	Complete tank				