

ARTIK 62 ELD Snow blower



Документы

Handle-bar and control box

Complete engine

Transmission assy

Snow thrower assy

Cylinder head

Cylinder and crankcase

Crankcase cover

Crankshaft and piston

Valves

Ignition system

Carburetor

Flywheel and coil

Starter lever


Control lever

Air filter

Muffler


Tank

Cover




изображение Handle-bar and control box

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	ZM000070	Handle				
2	1	ZM000071	Handlebar			DX; RIGHT	
3	1	ZM000122	Lever			DX; RIGHT	
4	1	ZM000073	Traction cable				
5	1	ZM000124	Spring				
6	1	ZM000074	Lever				
7	2	ZM000075	Knob				
8	1	ZM000304	Main board				
9	1	ZM000079	Plate				
10	1	ZM000080	Headlamp				
11	2	ZM000081	Washer				
12	1	ZM000086	Handle cover				
13	1	ZM000126	Bowden cable				
14	1	ZM000089	Lever			SX; LEFT	
15	1	ZM000127	Handlebar			SX; LEFT	
16	2	ZM000166	Self-locking nut			Pezzo set ricambi; Spare	
17	2	ZM000090	Pin			Pezzo set ricambi; Spare	
18	4	ZM000011	Bushing			parts set	
19	1	ZM000082	Spring				
20	2	ZM000298	Rubber protection				
21	1	ZM000176	Plate right				
22	1	ZM000084	Extension (lever)				
23	1	ZM000293	Extension (lever)				
24	1	ZM000076	Plate				
25	1	ZM000178	Plate				
26	1	ZM000078	Plate left				
27	1	ZM000077	Spring				
28	1	ZM000303	Plate right				
29	2	ZM000186	Lever				
30	2	ZM000187	Lever				
31	1	ZM000083	Switch				
32	1	ZM000085	Selector				
33	1	ZM000087	Cable				
34	1	ZM000177	Plate left				
35	1	ZM000292	Cable				
36	1	ZM000371	Light cable				
37	1	ZM000300	Pin				
38	1	ZM000296	Block				
39	1	ZM000372	Wiring				




изображение Complete engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000093	Belt cover				
2	1	ZM000099	Pulley				
3	1	ZM000095	Support				
4	1	ZM000011	Bushing				
5	1	ZM000012	Spring				
6	1	ZM000013	Pulley				
7	1	ZM000096	Pulley				
8	1	ZM000097	Belt			AOLIDA HTD 825-5M ;	
9	1	ZM000306	V belt			TRUFLEX G 4LXP930	



изображение Transmission assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000312	Rod				
2	1	ZM000092	Spring				
3	1	ZM000134	Pin (lever)				
4	2	ZM000311	Bush				
5	1	ZM000374	Lever support				
6	1	ZM000021	Shaft				
7	1	ZM000022	Wheel				
8	1	ZM000023	Rubber ring				
9	2	ZM000024	Flange				
10	1	ZM000101	Cover				
11	4	ZM000020	Bearing				
12	1	ZM000028	Shaft				
13	1	ZM000029	Flywheel				
14	1	ZM000030	Spring				
15	1	ZM000031	Fork				
16	1	ZM000033	Gear				
17	1	ZM000102	Key				
18	1	ZM000103	Shaft				
19	1	ZM000104	Complete wheel			Destra ; Right	
20	1	ZM000189	Bracket support				
21	2	ZM000172	Plate				
22	1	ZM000192	Plate				
23	1	ZM000190	Plate				
24	1	ZM000193	Plate (guide)				
25	2	ZM000032	Sleeve				
26	1	ZM000194	Gear case assy				
27	2	ZM000199	Fairled				
28	1	ZM000133	Lower handle				
29	1	ZM000310	Lever support				
30	1	ZM000380	Complete wheel			Sinistra ; Left	




изображение Snow thrower assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000149	Knob				
2	1	ZM000106	Rod				
3	2	ZM000151	Cardan				
4	1	ZM000152	Shaft				
5	1	ZM000108	Worm gear				
6	2	ZM000047	Sliding block				
7	1	ZM000373	Hood				
8	1	ZM000155	Bearing				
9	1	ZM000041	Key				
10	1	ZM000109	Pulley				
11	1	ZM000039	Spring				
12	1	ZM000158	Main board				
13	1	ZM000035	Pulley				
14	1	ZM000159	Foot socket				
15	1	ZM000111	Cable				
16	1	ZM000112	Spring				
17	1	ZM000113	Snow chute			Orientabile; Adjustable	
18	1	ZM000065	Spring				
19	1	ZM000066	Bracket				
20	1	ZM000162	Spacer				
21	1	ZM000051	Bearing				
22	1	ZM000050	Oil seal				
23	1	ZM000049R	Fan				
24	1	ZM000053	Shaft				
25	2	ZM000054	Bearing				
26	2	ZM000115	Bushing				
27	2	ZM000229	Washer				
28	4	ZM000166	Self-locking nut				
29	4	ZM000090	Pin				
30	2	ZM000059R	Tiller sx				
31	2	ZM000056R	Tiller dx				
32	1	ZM000168	Shovel				
33	1	ZM000169	Shovel support				
34	1	ZM000219	Cover dx				
35	1	ZM000220	Cover sx				
36	2	ZM000116	Gasket				
37	2	ZM000230	Spacer				
38	8	ZM000114	Guard cap				
39	2	ZM000119	Bushing				
40	3	ZM000062	Plate				
41	2	ZM000060	Bushing				
42	2	ZM000061	Cover				
43	1	ZM000117R	Gear				
44	1	ZM000226	Plate				

изображение Snow thrower assy


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	1	ZM000227	Countershaft support				
46	1	ZM000225	Tube support				
47	1	ZM000223	Cotter pin				
48	1	ZM000042	Cover				
49	1	ZM000224	Plate (guide)				
50	6	ZM000063	Plate				
51	1	ZM000120	Shaft				
52	1	ZM000222	Nipple				
53	1	ZM000360	Shaft				
54	1	ZM000362	Cotter pin				
55	1	ZM000361	Gasket				
56	2	ZM000366	Washer				
57	1	ZM000389	Labels kit				



изображение Cylinder head


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	4	L66150414	Screw				
2	1	L66150530	Tube				
3	1	L66150531	Gasket				
4	1	3055123R	Spark plug				
5	1	L66150532	Gasket				
6	1	L66150606	Gasket set				
7	1	L66150534	Gasket				
8	1	L66150316	Screw				
9	1	L66150605	Head comp.cylinder				

9*




изображение Cylinder and crankcase

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150535	Ignition coil				
2	1	L66150536	Shaft				
3	1	L66150537	Clip				
4	1	L66150353	Plug				
5	1	L66150538	Seal ring				
6	1	L66150316	Screw				
7	1	L66150480	Cable				
8	1	L66150539	Tube				
9	1	L66150606	Gasket set				
10	1	L66150699	Extension hose			Lungo; Long	




изображение Crankcase cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150540	Governor				
2	1	L66150541	Complete cap				
3	1	L66150542	Gasket				
4	1	L66150543	Bearing				
5	1	L66150544	Seal ring				
6	1	L66150545	Complete cap				
7	1	L66150352	Screw				
8	1	L66150606	Gasket set				




изображение Crankshaft and piston

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150546	Piston ring set				
2	1	L66150607	Piston assy				
3	1	L66150547	Piston pin				
4	4	L66150075	Snap ring				
5	1	L66150548	Connecting rod cpl.				
6	1	L66150543	Bearing				
7	1	L66150549	Shaft				
8	1	L66150550	Key				
9	1	L66150551	Band				





изображение Valves

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150563	Compensator				
2	1	L66150552	Plate				
3	2	L66150553	Equalizer rod				
4	2	L66150554	Slide				
5	1	L66150555	Camshaft assy				
6	2	L66150556	Valve				
7	4	L66150557	Valve				
8	2	L66150558	Clamp				
9	2	L66150559	Spring				
10	1	L66150560	Slide				
11	1	L66150561	Seal ring				
12	1	L66150562	Valve				
13	1	L66150605	Head comp.cylinder				




изображение Ignition system

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150612	Ignition system				
2	1	L66150613	Starter assy				
3	1	L66150566	Clip				
4	1	L66150316	Screw				




изображение Carburetor

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150570	Tube				
2	1	L66150571	Gasket				
3	1	L66150572	Safety ring				
4	1	L66150573	Gasket				
5	1	L66150704	Carburetor				BT6-107-12/13
6	1	L66150575	Spacer				
7	1	L66150702	Primer pump				
8	1	L66150696	Air lever	06/13			BT6-107-12/13
9	1	L66150700	Carburetor	06/13			BT6-107-12/13




изображение Flywheel and coil

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150567	Ignition coil				
2	2	L66150321	Screw				
3	1	L66150568	Flywheel				
4	1	L66150569	Fan				
5	1	L66150492	Case				
6	1	L66150493	Switch				



изображение Starter lever


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150596	Starter lever				




изображение Control lever

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150577	Rod				
2	1	L66150578	Spring				
3	1	L66150579	Spring				
4	1	L66150499	Rubber protection				
5	1	L66150185	Nut				
6	1	L66150497	Switch (stop)				
7	1	L66150240	Screw				
8	1	L66150580	Complete lever				
9	1	L66150382	Screw				

I° Serie / Ist Serie




II° Serie / IInd Series




изображение Air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150706	Air filter	06/13			BT6-107-12/13
2	1	L66150581	Air filter kit		05/13		BT6-107-12/13
3	1	L66150582	Starter lever		05/13		BT6-107-12/13
4	1	L66150583	Clip		05/13		BT6-107-12/13
5	1	L66150504	Knob		05/13		BT6-107-12/13




изображение Muffler

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150317	Screw				
2	1	L66150584	Complete muffler				
3	5	320000028R	Nut				



изображение Tank

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150608	Tank assy				
2	1	L66150295	Fitting				
3	1	L66150511	Cap				
4	4	L66150317	Screw				
5	2	L66150509	Clip				
6	1	L66150585	Tube				
7	1	L66150185	Nut				
8	1	L66150508	Switch				
9	1	L66150507	Knob				
10	1	L66150514	Filter				
11	1	L66150570	Tube				
12	1	L66150586	Tube				



изображение Cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150587	Cover				
2	1	L66150588	Guard				
3	1	L66150317	Screw				
4	1	L66150589	Cover				