


BV 126 Blower



Документы

Starter assy and engine

Fan assy




изображение Starter assy and engine



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	61070060	Screw				
2	2	50070148A	Spacer				
3	1	61070059	Gasket				
4	1	61070033	Gasket				
5	1	56510010R	Muffler				
6	1	61070055R	Plate				
7	2	3806014	Screw				
8	2	3960115R	Screw				
9	6	3916004R	Washer				
10	4	3801002R	Screw				
11	1	56510080	Deflector				
12	1	56510069	Gasket				
13	1	61070079AR	Tank cap				
14	1	61070006R	Gasket				
15	2	61070067R	Ring				
16	1	61070066	Piston pin				
17	1	61070107	Piston assy				
18	1	61070072A	Complete cylinder Ø34				
19	2	61070065R	Piston ring				
20	1	3055104R	Spark plug				
21	1	61070075	Seal ring				
22	1	61070074	Seal ring				
23	4	61070063	Screw				
24	1	61070061R	Crankcase				
25	1	3025019R	Ring				
26	1	61070070R	Key				
27	2	61070068	Spacer				
28	1	61070076	Bearing				
29	1	61070062	Gasket				
30	2	3035023R	Bearing				
31	1	61070069	Crankshaft				
32	3	61070073	Plug				
33	1	61070039R	Spring				
34	1	61070038R	Pawl				
35	1	61070053A	Clutch driver				
36	1	61070017BR	Flywheel				
37	1	4098377R	Band				
38	2	006000085	Screw				
39	2	3819005R	Washer				
40	1	61070012R	Cable				
41	1	094600097AR	Spark plug cap				
42	1	56510066R	Ignition coil				
43	1	094600450R	Fuel filter				
44	1	61130060	Gasket set				

изображение Starter assy and engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	1	3960070AR	Screw				
46	1	3073021AR	Tube				
47	1	094600169AR	Spring				
48	2	61070007R	Gasket				
49	2	3801051R	Screw				
50	1	61070004R	Insulator				
51	1	4161438R	Gasket				
52	1	2318992AR	Carburetor WYJ-282A				
53	1	61070003ER	Filter support				
54	2	61040020	Bushing				
55	2	61052009BR	Screw				
56	1	56510064R	Filter				
57	1	56510044	Cover				
58	2	3833073R	Washer				
59	1	094600451	Washer				
60	1	61070035BR	Starter pulley				
61	1	61070036R	Starter spring				
62	1	61070019AR	Starter rope				
63	1	093500397R	Starter handle				
64	1	072700089R	Bushing				
65	1	61102006BR	Starter assy				
66	2	61290088R	Tube				
67	1	61070011AR	Breather valve				
68	1	56510070	Labels kit				
69	1	4161211R	Bush				
70	1	006000829R	Washer				
71	1	56510088R	Tank				



Kit aspiratore / Tritturatore
Optional vacuum / Shredder kit



изображение Fan assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2317021R	Switch				
2	2	4191069BR	Plate				
3	1	56510004	Fan				
4	1	56510005	Knife				
5	1	56510006	Pin				
6	1	56510013	Throttle				
7	1	56510014	Throttle cable				
8	1	56510015	Lever				
9	1	56510018A	Tube				BT6-061-02/07
10	1	56510019A	Tube				BT6-061-02/07
11	1	56510036A	Cover				
12	1	56510086	Cover				
13	1	56510050R	Washer				
14	2	3960069AR	Screw				
15	1	56510009	Cover				
16	1	56510011A	Spring				BT6-061-02/07
17	1	56510034A	Half volute				
18	1	61070012R	Cable				
19	10	3960115R	Screw				
20	1	2317013R	Guard				
21	2	3960030R	Screw				
22	1	56510024	Lever				
23	1	56510063A	Cover				
24	1	56510049	Cable				
25	1	58040089	Lever				
26	1	3960067AR	Screw				
27	4	3801013R	Screw				
28	4	3916005R	Washer				
29	1	2318569	Screw				
30	1	003300201	Spindle				
31	1	2318703	Washer				
32	1	2318580	Screw				
33	1	2318813	Support				
34	1	2318568	Spring				
35	1	2318674	Repair kit				
36	1	2318571	Cover				
37	1	2318572	Primer pump				
38	4	2318585	Screw				
39	1	003300204	Fuel filter				
40	1	2318701	O-ring				
41	1	2318577	Adjuster nut				
42	1	2318570	Primer body				
43	1	2318189	Ring				
44	1	2318814	Valve				

изображение Fan assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	1	2318811	Pump body				
46	1	2318592	Valve				
47	1	2318812	Jet				
48	1	3801002R	Screw				
49	1	3916004R	Washer				
50	1	3818011AR	Washer				
51	1	3980012R	Nut				
52	1	3918003R	Washer				
53	1	56510089	Handle				
54	1	56510017	Elbow				
55	1	56510114	Suction tube				
56	1	56510114	Suction tube				
57	1	56510058B	Grassbag				
58	2	3960115R	Screw				