

## GV 48 TK ALLROAD 3 (K600) Lawnmower



### Документы

[Illustrated parts list](#)

[Cylinder head and valve](#)

[Cylinder and crankcase](#)

[Crankcase cover](#)

[Crankshaft and piston](#)

[Starter assy and flywheel](#)

[Carburetor](#)

[Air filter and muffler](#)

[Control lever](#)

[Tank](#)





## изображение Illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	66060398BR	Traction lever				
2	2	3024006R	Snap ring				
3	2	3064037R	Washer				
4	2	66060381BR	Pin				
5	1	66060421BR	Handlebar				
6	1	66060316AR	Brake lever				
7	1	66030276R	Engine break cable				
8	1	66060058CR	Traction cable				
9	1	66060231R	Band				
10	2	3910015R	Screw				
11	7	3916008R	Washer				
12	2	66070317R	Tightening handle				
13	1	66110014R	Shutter				
14	2	3045034R	Retainer washer				
15	1	66110610	Kit spring				
16	2	66070435R	Bushing				
17	1	66110026R	Deflector axle				
18	1	66030038	Grommet				
19	2	3045035R	Retainer washer				
20	1	66110100	Rod				
21	1	66070291R	Sector				
22	6	3801022R	Screw				
23	2	66030049AR	Support				
24	7	3914006R	Nut				
25	2	66030039	Plate				
26	4	3960031R	Screw				
27	1	66110637R	Deck				
28	1	66070415R	Guard				
29	1	66070744	Support set				
30	1	66070737	Labels kit				
31	1	66070439A	Lever group				
32	1	66110828R	Mulching cap				
33	1	3906150R	Screw				
34	1	66060384R	Washer				
35	1	66110594R	Mulching blade				
36	1	66030256R	Hub Ø22,2mm				
37	1	8202126R	Key				
38	3	3806076R	Screw				
39	3	66070228AR	Support				
40	7	3960137R	Screw				
41	1	66110845	Guard				
42	1	66070378A	Grassbag kit				
43	1	66070132R	Frame				
44	1	66070133R	Support				


## изображение Illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
45	1	66070330R	Grassbag				
46	1	66070035BR	Spring				
47	1	66030037R	Belt				
48	1	66070954R	Handle				
49	1	66070286CR	Lever				
50	1	3906164R	Screw				
51	1	8203374R	Spring				
52	1	66070036R	Spring				
53	1	66060010R	Roller				
54	1	66070017ER	Transmission				
55	1	66070980R	Spring				
56	1	66071084R	Pulley				
57	1	3022020R	Plug				
58	4	3933032R	Nut				
59	2	66070726R	Wheel cover				
60	2	66070729	Wheel kit				
61	4	3035023R	Bearing				
62	1	66070436R	Right sprocket				
63	1	66070756	Wheel cover				
64	2	3916015R	Washer				
65	1	66030044	Spacer				
66	4	3024012R	Snap ring				
67	2	66060030R	Bushing				
68	2	8202311R	Ring				
69	1	66070287AR	Rear axle				
70	1	66070437R	Left sprocket				
71	1	66070749	Axle kit				
72	4	3035023R	Bearing				
73	2	66070730	Wheel kit				
74	2	66070727R	Wheel cover				
75	1	66060425R	Handle kit				
76	1	66070233A	Guard kit				



## изображение Cylinder head and valve

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150368	Compensator				
2	2	L66150403	Slide				
3	1	L66150404	Camshaft assy				
4	1	L66150399	Washer				
5	1	3055123R	Spark plug				
6	2	L66150396	Stud				
7	1	L66150215	Head comp.cylinder				
8	4	L66150005	Screw				
9	4	L66150393	Screw				
10	2	L66150350	Plug				
11	1	L66150394	Cover				
12	2	L66150398	Spring holder				
13	2	L66150366	Valves spring				
14	1	L66150400	Suction/exhaust valve kit				
15	2	L66150708	Stud				
16	1	L66150401	Plate				
17	2	L66150402	Equalizer rod				
18	1	L66150736	Gasket set				
19		-	Not available for this product				
20	1	L66150471	Gasket				



## изображение Cylinder and crankcase




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150224	Crankcase assy				
2	1	L66150406	Guard				
3	2	L66150251	Screw				
4	1	L66150736	Gasket set				
5	1	L66150407	Stud				
6	2	L66150408	Stud				
7	1	L66150410	Reed valve				
8	1	L66150409	Seal ring				
9	1	L66150411	Screw				
10	1	L66150257	Spring				
11	1	L66150415	Flyweheel brake				
12	1	L66150413	Cap				
13	2	L66150414	Screw				
14	1	L66150353	Plug				
15	1	L66150419	Gasket				
16	1	L66150710	Tube				
17	1	L66150417	Governor arm shaft				
18	1	L66150035	Washer				






## изображение Crankcase cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150230	Cover				
2	7	L66150452	Screw				
3	3	L66150453	Screw				
4	1	L66150454	Plate				
5	2	L66150455	Bushing				
6	1	L66150456	Screw				
7	1	L66150232	Packing, breather chamber				
8	1	L66150458	Oil cap assy				
9	1	L66150457	Governor				
10	1	L66150463	Gasket				
11	1	L66150462	Oil seal				
12	1	L66150354	Washer				
13	2	L66150357	Plug				
14	1	L66150736	Gasket set				
15	1	L66150352	Screw				




## изображение Crankshaft and piston

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150070	Piston ring set				
2	2	L66150372	Retainer washer				
3	1	L66150342	Piston pin				
4	1	L66150217A	Piston assy				
5	2	L66150078	Connecting rod bolt				
6	1	L66150421	Connecting rod cpl.				
7	1	L66150355	Bearing				
8	1	L66150423	Crankshaft				
9	1	L66150081	Key				
10	1	L66150424	Washer				



## изображение Starter assy and flywheel

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150233	Starter assy				
2	1	L66150425	Flywheel				
3	1	L66150426	Fan				
4	1	L66150147	Pulley				
5	1	L66150376	Nut				
6	1	L66150427	Spark plug cap				
7	1	L66150428	Engine stop wire				
8	1	L66150429	Ignition coil				
9	1	L66150416	Screw				
10	3	L66150240	Screw				
11	1	L66150713	Cover				
12	1	L66150259	Screw				
13	1	L66150260	Slide				
14	1	L66150270	Starter handle				
15	1	L66150269	Starter rope				
16	1	L66150266	Starter spring				
17	1	L66150265	Pulley				
18	2	L66150263	Pawl				
19	2	L66150264	Spring				
20	1	L66150262	Spring				
21	1	L66150261	Washer				
22	2	L66150729	Screw				
23	1	L66150730	Control start				
24	1	L66150728	Tie rod				
25	1	L66150731	Shoe				
26	1	L66150737	Guard				
27	1	L66150726	Screw				
28	1	L66150727	Tie rod				
29	1	L66150734	Dust shield				




## изображение Carburetor


---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66151981	Insulator				
2	1	L66150732	Carburetor				
3	1	L66150714	Gasket				
4	1	L66150211	Repair kit				
5	1	L66150736	Gasket set				






6\*



## изображение Air filter and muffler

---


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150735	Muffler assy				
2	1	L66150715	Air filter				
3	1	L66150716	Sponge				
4	1	L66150717	Air filter kit				
5	2	004400959R	Nut				
6	1	L66150736	Gasket set				
7	2	L66150185	Nut				



## изображение Control lever

---

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150236	Rod				
2	1	L66150237	Spring				
3	1	L66150733	Complete lever				
4	1	L66150448	Spring				
5	1	L66150447	Control lever				
6	1	L66150185	Nut				
7	1	L66150382	Screw				
8	2	L66150464	Screw				



## изображение Tank

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150437	Cap				
2	1	L66150436	Complete tank				
3	1	L66150185	Nut				
4	1	L66150438	Washer				
5	1	L66150251	Screw				
6	1	L66150439	Filter				
7	1	L66150239	Stud				
8	1	L66150440	Clip				
9	2	L66150435	Clip				
10	1	L66150432	Tube				